



Manufactured By KBD, Inc.

TUBE INSTALLATION INSTRUCTIONS AND PRECAUTIONS

1. Be certain lamp is unplugged before installing new tube.
2. Remove protective wire guard.
3. Remove two shield screws; slide shields toward center of lamp and remove.
4. Remove tube (if present).
5. Position new tube with red mark on your right and facing you.
TUBE MUST BE INSERTED WITH RED MARK ON YOUR RIGHT AND FACING YOU, OTHERWISE, TUBE LIFE WILL BE SHORTENED.
6. Insert new tube inside (between) tube holders (terminals); rotate into position. (See diagram). **FAILURE TO PROPERLY PLACE TUBE INSIDE OF TERMINALS MAY RESULT IN BROKEN METAL LEADS AND/OR GLASS EXHAUST, RUINING THE BULB. THE BREAKAGE THAT OCCURS DURING INSTALLATION IS NOT A WARRANTY ITEM.**
7. With your thumbs move terminals slightly away from the glass ends of tube to make sure there is a good connection.
8. Replace shields, screws and wire guard.
9. Plug in lamp and set timer to 10 minutes.
BE SURE TO PUT YOUR PROTECTIVE EYEWEAR ON BEFORE STARTING LAMP.
10. FOR LAMPS WITH A "START" BUTTON: Depress Start button for 4-6 seconds and release. Blue glow should appear. Allow lamp to warm up for 2-3 minutes, reset timer to desired exposure; then begin use.
FOR LAMPS WITH AN "ON/MIN" SWITCH: Set timer for 10 minutes, Allow lamp to warm up for 2-3 minutes, reset timer to desired exposure; then begin use.

TROUBLE SHOOTING (When lamp fails to start)

1. Make sure lamp is disconnected before checking tube.
2. Remove protective wire guard.
3. Remove two shield screws and slide shields toward center of lamp and remove.
4. With your thumbs move terminals slightly away from the glass ends of tube to make sure there is a good metal to metal contact. (See diagram)
5. Reinstall tube shields and protective guard.
6. Plug in your lamp and try again.

NOTE: If lamp still fails to start. Please call our Customer Service at (800) 544-3757 between 8:30 AM and 3:30 PM. EST.

